

WBC Brand – Acrylic Based Pressure Sensitive Adhesive Hook and Loop

Description: Acrylic type adhesive

Life of product: 6 months from date of manufacturer

Performance: Resistance of elevated temperature and to plasticize migration.
Good U.V and water resistance

Typical Application: Adhesion to a variety of surfaces
Paper, wood, polythene, polyester, metal, glass, vinyl, aluminum,
and PVC (soft and hard)

Range of temperature after application: -20° to 120° C. = 248° F

Application Guide:

- To be avoided on surfaces – humidity, dust, oil, etc.
- Application temperature from +5° to +70° C
- Hard pressure and 48 hours for bonding time are necessary

Customer attention: The above suggestions are not to be considered guarantees. The customer should test our product on their working conditions and/or products.